

EN

H375iS

CONGRATULATIONS

H375iS

Get the convenience of push-to-talk calls together with a sleek design in an affordable package.

- **Private Calls:** Stay in touch with your family, friends, and colleagues with the simple touch of a button.
- **My Phone, My Way:** It's your phone - make it that way. Customize your home screen with personal pictures, wallpapers and ring tones.

Caution: Before assembling, charging, or using your phone for the first time, please read the important safety, regulatory and legal information provided with your product.



This product meets the applicable SAR limits of 1.6 W/kg (FCC & IC) and 2.0 W/kg (ICNIRP). The limits and guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The highest SAR values measured for this device are listed in the regulatory information packaged with your product.

YOUR PHONE

The important keys & connectors



Note: Your phone might look a little different.

Contents

MENU MAP	1
LET'S GO	2
BASICS	4
CALLS	8
PUSH-TO-TALK.....	10
ADVANCED FEATURES	12
MOTotalk	18
SDG CALLS.....	25
WEB.....	26
TEXT ENTRY	27
CONTACTS	28
MESSAGING	29
PERSONALIZE.....	31
WALLPAPER.....	32
MULTIMEDIA.....	33
BLUETOOTH™ WIRELESS	35
TOOLS	37
SECURITY	40
SAFETY, REGULATORY & LEGAL	42

MENU MAP

MAIN MENU



Recent Calls



Contact

- [New Contact]
- [New SDG List]
- [New Msg Group]



Messages

- [Create Message]
- Voice Mail
- Inbox
- Drafts
- Outbox
- Sent Items
- Net Alert



Web

- Net



Multimedia

- Media Center
- My Images
- My Music
- My Video
- Ring Tones
- Voice Record



Push To Talk

- Call Alert
- PT Manager
- Quick PTT
- PTT Options
- MOTotalk
- PTT Help



Games and Apps

- Buy More
- Alarm Clock Plus
- My Images
- My Music
- My Video
- Java Systems



Tools

- My Info
- Profiles
- Alarm Clock Plus
- Bluetooth
- GPS
- Datebook
- Call Timers
- Memo



Settings

- (See **Settings** menu)

LET'S GO


Let's get you up and running

ASSEMBLE & CHARGE




Caution: Please read “BATTERY USE & SAFETY”

TURN IT ON & OFF

To turn on your phone, press and hold Power/End for  a few seconds or until the display turns on. If prompted, enter your four-digit unlock code.




Note: If you press Power/End  for more than four seconds, the phone will turn on in Transmitters Off mode.


To turn off your phone, press and hold Power/End .

BASICS


ABOUT THIS GUIDE

This guide shows how to locate a menu feature as follows:

Find it: Menu  >  Settings > Phone Calls

Press the **Menu**  to open the main menu.

Press the navigation keys to scroll to the  **Settings** menu option, and press **OK**  to select it.

Press the navigation keys to scroll to **Phone Calls**, and press **OK**  to select it.

HOME SCREEN













Your phone shows the home screen when you are not on a call or using the menu.



Note: Your home screen might look different from the one shown, depending on your service provider.

Soft key labels in the home screen show the current soft key functions.

Indicators at the top of your phone's display provide important status information.

Indicators			
	Signal Strength		No Service
	Active Phone Line		New Message
	Speaker On		Packet Data
	Speaker Off		Battery Level
	Ringer Off		Bluetooth™ On
	Vibrate All		New Voicemail

CAROUSEL MENU

Get quick access to your favorite applications, right on your home screen.

OPEN APPLICATIONS



- 1 Press the Navigation Key left or right until you highlight the desired application.
- 2 Press **OK**  to launch the Application.

Note: Availability of the Carousel Menu is dependent on your service provider.

CHOOSE APPLICATIONS

Customize the Carousel Menu with your most often used applications.

Find it: Menu  **> Setting**  **> Personalize > Carousel AUTO HIDE**

To set the Carousel Menu to hide when not in use, press **Menu**  **> Setting**  **> Personalize > Carousel > Auto Hide**

ADJUST VOLUME


Press the volume keys up or down to:

- change the earpiece volume during calls
- change the ringer volume from the home screen
- turn off a call alert before answering the call



Tip: While on the home screen, press and hold the volume key down until your phone vibrates to set your ringer to **vibrate all**.

NAVIGATION KEY

Press the navigation key up, down, left, or right to scroll to items in the display. When you highlight an item, press **OK**  to select it.



TRANSMITTERS

Consult airline staff about the use of the **Transmitters Off** feature during a flight. Turn off your phone whenever instructed to do so by airline staff.




Find it: Menu  >  **Settings** > **Advanced** > **Transmitters** > **off**

Transmitters Off turns off your phone's calling and Bluetooth features in situations where wireless phone use is prohibited. You can use the phone's other Non-calling features when the transmitters are turned off.

Note: When you select **Transmitters Off**, all wireless services are disabled. Emergency calls can still be made.

CALLS

It's good to talk



MAKE & ANSWER CALLS Enter a number, then press Talk . To answer a call, press Talk . To end a call, press Power/End .



HANDS FREE


Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

During a call:

- To use the speakerphone, press Speaker.
- To connect a Bluetooth device, press **Menu**  >  **Recent Calls**
Settings > connections > Bluetooth.

RECENT CALLS

Find it: **Menu**  >  **Recent Calls**

Tip: When you are in the home screen, you can press Talk  to go to **Recent Calls**.

The recent calls list contains information associated with the last 20 calls you have made and received.

To display call details, highlight an entry and press **OK** .

EMERGENCY CALLS



Note: Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked.

Emergency numbers vary by country.

Your pre-programmed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

1. Enter the emergency number.

2. Press Talk  to call the emergency number.

Note: Emergency calls can't be made while the keypad is locked, or if the phone is displaying a **No Service** message. To unlock the keypad, press **Menu**  > .

Note: Your phone can use location based services (GPS and AGPS) to help emergency services to locate you. See “**LOCATION SERVICES**”.

COOL DOWN

In very limited circumstances, such as where your phone has been exposed to extreme heat, you may see “Cool Down” messages. To avoid possible damage to your battery and phone, you should follow these instructions until the phone is within its recommended temperature range. When your phone is in “Cool Down” mode, only emergency calls can be made.

PUSH-TO-TALK



One or more, talk to them all.


PRIVATE CALLS

Private calls are push-to-talk calls between two people.

MAKE AND ANSWER PRIVATE CALLS

To **make** a private call:

- Enter the recipient's PTI number.
- Press **Menu**  >  **Contacts**, and select a contact that has a PTT number




To **talk**, press and hold the PTT Button.

To **listen**, release the PTT Button.

To **answer** a private call, press the PTT Button after the caller has stopped talking.

To **end** a private call, press Power/End  or do nothing. The call will end after a few seconds.

SET PUSH-TO-TALK SPEAKER

You can listen to push-to-talk calls through your phone's speaker or earpiece. Press Speaker  to turn the speaker on or off.



CALL ALERTS

Use call alerts to tell someone you want to speak to them.

To **send** a call alert:

- Enter a Private ID, and press **Alert**. When prompted, press the PTT Button.
- Press **Contacts**, and highlight a contact containing a Private ID. Press **Alert**, and press the PTT Button when prompted.

When you **receive** a call alert, you can:

- **Answer:** Press the PTT Button to begin a private call with the sender.
- **Queue:** Press **Queue** to store the call alert to the call alert queue.
- **Clear:** Press **Clear** to dismiss and delete the call alert.

Note: Call alerts will automatically be moved to the queue after a few minutes of inactivity. You won't be able to make phone calls or private calls until the call alert is moved, or you've chosen one of the options above.

TURN OFF A CALL ALERT

You can press the volume keys to turn off a call alert before answering the call.

ADVANCED FEATURES

Note: These features may not be offered by your service provider.

Group calls, Talkgroups and Hubs



A group call is similar to a private call, but is made to all members of a Talkgroup at once. A Talkgroup is a predetermined group of your service provider's customers. A hub consists of 1 to 4 Talkgroups.

You must join a Talkgroup to make or receive calls on that Talkgroup by joining the hub it belongs to.

On your phone, all group calls you make are hub calls. Group calls you receive are hub calls or Talkgroup call to Talkgroups in the hub you have joined.

Your sales representative or your service provider establishes Talkgroups and hubs for you. You can choose a name for each each when you create entries for them in Contacts.

Join a hub:

- 1 Press .
- 2 Enter the hub number using the keypad.
Or scroll to the hub name in Contacts or recent calls list.
- 3 Press  under **Join**.


Create a talkgroup hub

- 1 Begin creating a new Contacts entry. See “store a phone number or private ID”.


- 2 Assign the hub Contacts type to the entry.
- 3 Assign the Talkgroup number as the number of the hub.

This creates a hub with the same number as the Talkgroup it contains. You cannot add any more Talkgroups to the hub.

View hub details

- 1 From the recent calls list, scroll to the hub.
- 2 Press .
- 3 Select **Details**.

Make group calls

- 1 Press . Enter the hub number using the keypad.
Or scroll to the hub name in Contacts or recent calls list.
- 2 Proceed as if making a private call.

Receive group calls




When you receive a group call, the following appears on the screen:

- The name of the hub
- The name of number of the primary Talkgroup in the hub
- The private number of the person speaking

To answer a group call:

- Proceed as if answering a private call. Only one person at a time may speak during a group call.

Set Talkgroup Scan

- 1 From the main menu, select  >  **Push To Talk** > **PTT Options** > **Scan**.
- 2 Press **OK** .
- 3 Select to **On**.

4 Press **OK** .

To set your phone to receive group calls only from the primary Talkgroup in a hub:

- Select to **Off** in step 3.

Turn off group calls

1 From the main menu, select > **Push To Talk > PTT Options > Tkgrp Silent**

2 Press **OK** .

3 Select to **On** if you don't want to hear group calls. Or select **Off** if you want to hear group calls.

Emergency group calls

An emergency group call is a hub call that takes priority over all other phone activities in the phone making the call and sounds a special emergency tone in the phones receiving the call.

When you make an emergency group call, a group call is made using a designated emergency hub or the hub you currently belong to.

A designated emergency hub must be created for you by your service provider and is stored in your SIM card.

If no designated emergency hub has been created for you, emergency group calls consider rephrasing using the hub you currently belong to. If no designated emergency hub has created for you and you have not joined a hub, you cannot make emergency group calls.

Make an emergency group call

Caution: Making an emergency group call ends all other activities on your phone, including 911 emergency calls.

To make an emergency group call:

- 1** Press and hold EGC key for 3 seconds to start the emergency group call.
- 2** Press and hold the PTT button on the side of your phone to talk. Begin talking after your phone emits a chirping sound.
- 3** Release the PTT button to listen.

To end an emergency call:

- Press and hold EGC key for 3 seconds.

An emergency group call automatically ends if there is no activity for 30 seconds.

Emergency group calls you make or receive do not appear in the recent calls list.

Receive an emergency group call

When receiving an emergency group call, your phone sounds a special emergency tone, unless your phone is set to silent.

To answer an emergency group call:

- Proceed as if answering a private call.

Isolated operation

Isolated Operation lets you continue to make and receive group calls on the hub you last used, within a limited

coverage area, even if you lose network coverage.

When you lose network coverage during a phone call, private call, group call or data transfer, the call or data transfer ends. But you can make and receive new group calls on the hub you last used.

If the **One Touch PTT** settings on your phone would prevent you from making group calls on the hub you last used, these setting are overridden while you phone is in Isolated Operation.

Caution: You cannot make emergency group calls in Isolated Operation, even if the hub you last used is the designated emergency hub. You must have network coverage to make emergency group calls.

If the designated emergency hub is the hub you last used when you lost network coverage your phone treats the hub you used before the designated emergency hub as the hub you last used.

Call alert status message

You cannot send call alerts that include text message up to 10 characters long. These messages are stored in your SIM card when you receive your phone. There are 10 you can choose from.


If the phone you send the call alert to has this capability, the text message appears on that phone when the call alert is received. If the phone you send the call alert to does not have this capability, the call alert appears without the text message.

Send a call alert status message

1. Proceed as you would when sending any call alert.
2. When the **Ready to Alert** screen appears, choose the text message you want to send:

Scroll left or right to display the message you want to send.

Or

Press  under **Select** to view all messages and select the one you want to send.

Or

3. Press the PTT button until **Alert Successful** appears on the display.

Receive a call alert status message

When you receive a call alert that includes a text message, the text message appears as the part of the call alert information when you receive the call alert and in the recent calls list.

MOTOtalk

MOTOtalk allows direct two-way phone-to-phone communications between two or more phones equipped with MOTOtalk. You can make and receive MOTOtalk calls even when network service is not available. You can talk to anyone on your code and channel within your range.

Note: MOTOtalk may not be offered by your service provider.

Note: Range will vary based on terrain, man-made structures and atmospheric conditions.

MOTOtalk allows you to:

- Use up to 10 channels
- Communicate with standalone MOTOtalk radios

Note: MOTOtalk is not compatible with older Family Radio Services products.

The following features and main menu items will not be available while in MOTOtalk:

- On-network phone calls
- On-network Private calls
- Data transmission
- Incoming message notification
- Musical ring tones
- Call forwarding
- Messages
- Call Timers
- Call alerts
- Voice records

Using MOTotalk

To set your phone to MOTotalk


Find it: Menu  >  **Push To Talk** > **MOTotalk**

- 1 Select **Go To MOTotalk**
- 2 Press **OK** .

Switching to MOTotalk Please Wait displays.

After a few seconds, the MOTotalk idle screen appears. The channel you are set to appears on the first line of the display. your code is set to appear on the second line of the display. **MT Ready** appears on the third line of the display.

Note: When switching from the network to MOTotalk, the last channel and code that were set will appear on the MOTotalk idle screen.

While in MOTotalk, this icon  appears on the display, indicating that there is no network signal and MOTotalk is active.

Exiting MOTotalk

To set your phone to network mode when MOTotalk is active:

Find it: Menu  >  **Push To Talk** > **MT Options**

- 1 Select **Exit MOTotalk**
- 2 Press **OK** .

Talk Range

Phones used in MOTotalk mode should be a minimum of 6 feet apart to maximize performance and improve transmission range.

Channels and Codes

Your phone has 10 channels and 15 codes.



Channels are divided into sets of frequencies that allow you to make and receive MOTOtalk calls. Other parties may also be talking on the same channel.

Codes help to minimize interference from unwanted messages and other disturbances when you are on the same channel as others.



To have a conversation, all parties must be on the same channel and code. For private MOTOtalk calls, the person you are calling must be on MOTOtalk and set to the same channel to receive your call.

Note: When making a code call, all parties that are on your code and channel can hear your conversation.

To set a channel:

- 1 From the MOTOtalk idle screen, press  under Edit
- 2 Scroll to Channel, press **OK**.
- 3 Select a channel, press **OK**.
- 4 When you are finished, press  under Back to return to the MOTOtalk idle screen.


To set a code:

- 1 From the MOTOtalk idle screen, press  under Edit.
- 2 Scroll to Code, press **OK**.
- 3 Select a code, press **OK**.
- 4 When you are finished, press  under Back to return to the MOTOtalk idle screen.

Private MOTotalk Calls

You can have a private conversation with another person using MOTotalk. When on a private MOTotalk call, no other parties can hear your conversation. In order to make a private MOTotalk Call, you must use the valid 10-digit Personal Telephone Number (PTN) of the person you are calling. The person you are calling must be in MOTotalk and set to the same channel to receive your call.

If you receive an error message:




- You may not be using a valid PTN.
- The person that you are trying to reach may not be in MOTotalk .
- The person that you are trying to reach is set to a different channel or is out of range.

Private only

To limit MOTotalk to private conversation only, set your code to Private Only. In this mode, code calls will be ignored and only private calls can be made or received.

Note: You will be required to enter a valid PTN before pressing the PTT button.

To set a code to Private Only:

- 1 From the MOTotalk idle screen, press  under **Edit**.
- 2 Scroll to Code, press **OK** .
- 3 Select **PVT only**, press **OK** .

Making a Private MOTotalk Call

- 1 Enter the 10-digit PTN of the person you want to call on your channel. **-or-**
 - a. Scroll to a number or name in **Contacts**. **-or-**
 - b. Scroll to a number in the recent calls list.
- 2 Press and hold the PTT button. Begin speaking after your phone emits the MOTotalk tone.
- 3 Release the PTT button to listen.

The number or name of the person you are calling will appear in the first line of the display.

Receiving a Private MOTotalk Call

The number or name of the person who initiated the call will appear in the first line of the display.

Note: You can reply within 6 seconds simply by pressing the PTT button.

Ending a Private MOTotalk Call

A private MOTotalk call will end if there is no communication for 6 seconds.

Note: A private MOTotalk call may be interrupted during the 6 second idle time by another code call or private call.

The display will return to the MOTotalk idle screen.

Emergency Calls Using MOTotalk

Emergency phone calls can still be made even when you are not connected to network service.

Dial 911 to be connected to an emergency response center.

If you are on an active MOTotalk call, you must end it before calling 911.

Setup Options

MOTOfalk setup options are available in the MT Options screen in both network and MOTOfalk modes.

To access Setup Options in network:

Find it: Menu  >  **Push To Talk** > **MOTOfalk**

- 1 Select Setup
- 2 Press **OK** .

To access Setup Options in network:

Find it: Menu  >  **Push To Talk** > **MT Options**



- 1 Select **Setup**
- 2 Press **OK** .

You can set your phone to:

- Launch directly into MOTOfalk when you select MOTOfalk from the main menu.
- Notify you periodically with a tone that you are in MOTOfalk.


Using Direct Launch

To set your phone to launch MOTOfalk when you select MOTOfalk from the main menu:



- 1 From the **Setup** screen, scroll to **Direct Launch**.
- 2 press **OK** .
- 3 Select **On**.
- 4 Press **OK** .

Note: If Direct Launch is set to **On**, you will not see MT Options when you select MOTOfalk from the main menu. In order to have access to your setup options,

Direct Launch

must be set to **Off**. Or you can also access setup options while in MOTOtalk by pressing  and selecting MT Options.


To turn off Direct Launch :

- 1 From the **Setup** screen, scroll to **Direct Launch**.
- 2 Press **OK** .
- 3 Select **Off**.
- 4 Press **OK** .

Your phone now displays MT Options when you select MOTOtalk from the main menu.



Using State Tone

To set your phone to notify you with a tone that you are in MOTOtalk:

- 1 From the **Setup** screen, scroll to **State Tone**.
- 2 Press **OK** .
- 3 Select the time frame during which you want to be indented that you are in MOTOtalk.

For example, if you select 1 hour, you will be notified every hour that you are in MOTOtalk.

To turn off **State Tone**:

- 1 From the **Setup** screen, scroll to State Tone.
- 2 Press **OK** .
- 3 Select **Off**.
- 4 Press **OK** .

SDG CALLS

Need to talk to more than one person at a time? With SDG (Selective Dynamic Group) calls you can talk to up to 20 people at a time.

Note: SDG calls may not be available from your service provider. To store groups on your phone you need a group-call-capable SIM card. Contact your service provider for more information.

CREATE SDG LISTS IN CONTACTS

Find it: Menu  >  **Contacts**

1. Select **[New SDG List]**.
2. If you want to assign a name to the SDG list, enter the name.

Note: If you do not assign a name, the SDG list is named "SDG" followed by the number of members in the SDG list. For example, "SDG (8)" for an SDG list with eight members.

3. Add Private IDs.
4. Press **Save**.

MAKE SDG CALLS

1. From Contacts or the recent calls list, scroll to or select the SDG list you want.
2. Press the PTT button.

WEB


Find it: Menu  >  Web > Net

Note: Your service provider may charge you to surf the web or download data.

GO TO A WEB SITE



- 1 From the home page, select **Go to URL**.
- 2 Press **Edit**.
- 3 Enter the web address and press **Done**.
- 4 Press **Option** and select **accept** to go to the web site.

CREATE A BOOKMARK

- 1 While on a web page, press and hold **Menu**  > **Bookmark Page**.
- 2 Name the bookmark and select **Save**.

ACCESS A BOOKMARK

From a web page:


- 1 Press and hold **Menu**  > **View Bookmarks**.
- 2 Highlight a bookmark and press **OK** , or press its number on the keypad.


TEXT ENTRY

Your phone provides convenient ways to enter text.

CHANGE CHARACTER INPUT MODE

While entering text, press Menu , options.

Options	
Alpha	Enter a single letter at a time. Press a key to cycle through the characters. To select a character, press another key or wait for 1 second.
Word	Predicts words as you enter text. Press the Navigation Key right to accept word. If incorrect, press and hold the Navigation Key down for other options. Highlight a word and press OK  to select.
Symbols	Enter symbols.
Numeric	Enter numbers.
Text Input Settings	Select desired entry language and Word Prediction features.
Insert	Select an item to be inserted. Note: Only available with MMS.

Tip: When entering text, press and hold  to change letter capitalization (Abc > ABC > abc).

CONTACTS


STORE A PHONE NUMBER OR PRIVATE ID

Find it: Menu  >  Contacts > [New Contact]

- 1 Enter a name for the new contact. Each contact's name can contain up to 20 characters.
- 2 Select a ringtone.
- 3 Select a type for the contact (Mobile, Private1, Private2, Work1, Work2, Home, Email1, Email2, Fax, Pager, Talkgroup, HUB, SDG, Msg Group, IP, or Other). Choose Private1 or Private2 to store a Private ID.
- 4 Enter the number for the contact and press **Save**.

CALL A STORED PHONE NUMBER OR PRIVATE ID

Find it: Menu  >  Contacts

- 1 Scroll to the contact.
- 2 If the contact contains more than one number, scroll left or right until the type of number you want to call appears (such as **Mobile**, **Private1**, **Work1**, **Work2**, **Home**).
- 3 If you chose a phone number, press Talk  to begin a call. If you chose a Private ID, Talkgroup ID, or SDG list, press and hold the PTT Button to start a call.


MESSAGING


Find it: Menu  >  **Messages**

Your phone can use both SMS and Multimedia Messaging Service (MMS) messaging. The type of messaging your phone uses is determined by your service provider.

CREATE & SEND MESSAGES

Find it: Menu  >  **Messages** > **[Create Message]**

- 1 Enter the phone number of the person you want to send the message to and press **OK**  or press **Search** to select a contact or recent call.
- 2 Enter your message in the **Message** field.
- 3 Or add a picture, sound, or quick note:

- Quick notes are short, pre-written phrases. Press **QNotes** to enter a quick note.
- To insert pictures, sounds (audio files), or voice recordings into the body of your message, press **Menu**  > **Insert** > **Insert Picture**, **Insert Audio**, **Insert Video** or **Record Voice**.

Note: To remove an item from a message, highlight it and press **Delete**.

- To attach a file to the end of your message, select....**MORE**.... > **Attach** > **[New Attach]** > **Browse Pictures**, **Browse Audio**, **Record Voice**, **Browse Video**.

Note: You can only attach pictures and audio files if they're not forward locked or DRM-protected.

Tip: To remove an attachment, select **Attach**. Highlight the



attachment to remove, and press **Menu**  > **Unattach**.

Note: You can't attach or insert files in SMS messages.

4 When finished, press **OK** .

5 To send the message, press **Send**.

RECEIVE MESSAGES

- To view the message, press **Read**.
- To dismiss the message notification, press **Exit**.
To read your messages later, press **Menu**  > 
Messages > Inbox.

MESSAGE GROUPS

You can create a message group to send messages to a group of up to 20 contacts.

Note: Your service provider may not support this feature.

CREATE MESSAGE GROUPS

Find it: **Menu**  >  **Contacts > [New Msg Group]**

1 Select **[Add Member]** and select the contacts you want to add to the group.

2 When you're finished press **Done**.

3 Enter a name for the group in the **Name** field.

Note: If you don't name the group, it will be named Msg Group followed by the number of group members. For example, Msg Group (3).

4 Press **Save**.

VOICEMAIL

To receive voicemail, you'll need to contact your service provider to set up a voicemail account.

RECEIVING A MESSAGE

To listen to the message, press **Call**.

To dismiss the notification, press **Back**.



To listen to your messages later, press **Menu**  > 
Messages > Voice Mail.

PERSONALIZE

RINGTONES

Find it: **Menu**  >  **Multimedia > Ring Tones**

- 1 Make sure **Vibrate All** is set to **Off**.
- 2 Scroll through the list of ringtones and select one to assign. **Vibrate** sets your phone to vibrate instead of making a sound. **Silent** sets your phone to neither vibrate nor make a sound.
- 3 Select the features, such as **Messages**, you want to assign the ringtone to.
- 4 When you're finished press **Done**.

Note:  appears if the phone is set to **Silent**.  appears if the phone is set to **Vibrate All**.

SET TO VIBRATE

You can set your phone to vibrate for all calls and alerts.

Find it: **Menu**  >  **Multimedia > Ring Tones > Vibrate All**

Set this option **On** or **Locked**.

To turn the ringer on when **Vibrate All** is set to **On**, press

the volume key up. To turn the ringer on when **Vibrate All** is set to **Locked**, press and hold the volume up key until the phone vibrates, then press the volume key up again.

BACKLIGHT

Set the amount of time the backlight remains on or turn it off to extend battery life.

Find it: Menu  >  **Settings > Display/Info > Backlight**

WALLPAPER

Find it: Menu  >  **Settings > Display/Info > Wallpaper**

- 1 Select Wallpaper.
- 2 Scroll through the list of pictures and press **OK** to select a picture.

You can set the wallpapers to change automatically by selecting **Auto Cycle**.

MENU LANGUAGE

Find it: Menu  >  **Settings > Display/Info > Language**

PROFILES

Your phone has different profiles. You can customize ringtones, display settings, call settings, volume, and call filters.

Find it: Menu  >  **Tools > Profiles**

MULTIMEDIA

MY MUSIC







PLAY MUSIC FILES

Find it: Menu  >  Multimedia > My Music

To play a **Song**, **Album**, **Playlist**, **Genre**, or **Artist**, highlight it and press **Play**.


To view the contents of an **Album**, **Playlist**, **Genre**, or **Artist**, highlight it and press **OK** .

MUSIC PLAYER CONTROLS

Options	
Play/Pause	To play a song, press OK  To pause a song, press OK 
Next/ Previous Song	Press Fast Forward(next)  or Rewind (previous) 
Fast Forward/ Rewind	Press Fast Forward(next)  or Rewind (previous) 

PLAYLISTS

Find it: Menu  >  Multimedia > My Music > Playlists > [Create New]


To add a song to the Favorites playlist, highlight it and press **Menu**  > **Add To Favorites**.



PODCASTS


Find it: Menu  >  Multimedia > My Music > Podcasts

PODCAST HIGHLIGHTS

Use highlights to mark parts of a podcast.

To add a highlight, press **Menu**  > **Add Highlights**. Press **On** to mark the beginning, and **Off** to mark the end. When finished, press **Back**.

Tip: When playing a podcast, press **Menu**  > **Clear** to delete a highlight, or press **Menu**  > **Edit Highlights** > **Clear All Highlights** to delete them all.

Press the Navigation Key left or right to move between highlights, or press **Menu**  > **Highlights Only** to skip everything not marked as a highlight.


FM RADIO

Note: Your service provider may not support FM radio.

Find it: **Menu**  >  **Multimedia** > **My Music** > **FM** > **Radio**

Note: A wired 2.5mm PTT headset is required for radio use.

FIND A STATION

Press the navigation key up or down to search for stations, or press **Menu**  > **Enter Freq.** to use your key pad to enter a station.

STATION PRESETS

Your phone can store up to nine station presets.

To store a station, tune into it, and press and hold a number (1-9) on your keypad.


To tune in a station preset, press its number.

MY IMAGES

My Images lets you browse, edit, and view images on your phone.

VIEW IMAGES

Find it: Menu  >  **Multimedia > My Images**


Press **Menu**  > **Slideshow** to view a slide show of all the images in the current folder.

Press “**Left**” and “**Right**” to switch between images stored on the phone’s memory.

MY VIDEOS

Find it: Menu  >  **Multimedia > My Videos**

VIEW VIDEOS

To view a video, select a folder, highlight the file, and press **OK** .

Tip: Videos are displayed in portrait by default. To change to landscape, press Menu  > **Full Screen**.

BLUETOOTH™ WIRELESS

Lose the wires and go wireless

TURN BLUETOOTH POWER ON OR OFF

Find it: Menu  >  **Tools > Bluetooth > Setup > Power**



Note: To extend battery life, turn Bluetooth off when not in use.

CONNECT DEVICES

Note: This feature requires an optional accessory.

1 Make sure the Bluetooth device is discoverable.

Note: Refer to the Bluetooth device guide for details.

2 Press Menu  >  Tools > Bluetooth > Audio Devices > [Look for Devices] to connect to an audio Bluetooth device.

Press Menu  >  Tools > Bluetooth > Pair to Devices to connect to any other type of Bluetooth device.

3 Select your Bluetooth device from the list.

4 Press Yes when you're prompted to bond.

5 If prompted, enter the Bluetooth PIN, such as **0000**.

6 Press **OK** .

Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

RECONNECT DEVICES

To automatically reconnect to a paired device, simply turn it on.

To manually reconnect with a paired device, select the device in the **Audio Devices** list.

DISCONNECT DEVICES

To automatically disconnect from a paired device, simply turn off the device.

To manually disconnect from a paired device, select the device in the **Audio Devices** list. When prompted to disconnect, press **Yes**.

TOOLS

DATEBOOK



Features

Create datebook event

To create a new Datebook event press

Menu  >  **Tools** > **Datebook** > **[New Event]**

See datebook events

To see a datebook event press **Menu**  >  **Tools** > **Datebook**. Press the navigation key left or right to see the day and up or down to see the events.





VOICE RECORD

Features

Create a voice record

Press **Menu**  >  **Multimedia** > **VoiceRecord** > **[New VoiceRec]**. Press **OK**  to stop recording.

Playing voice records


Press **Menu**  >  **Multimedia** > **VoiceRecord**. Highlight a voice record and press **OK**  to play it. To stop the voice record while it's playing, press **OK** .

Note: Recording of calls is subject to varying State and Federal laws regarding privacy and recording of conversations. Always obey the laws and regulations on the use of this feature.

ACCESSIBILITY

VOICE PLAYBACK

Your navigation and selections, read out loud.

To turn on voice readouts, press **Menu**  **Settings** > **Voice Playback** > **Speak Text**.





To use voice readouts:

- **Menus:** In menus, highlight an item (it will be read out loud).
- **Dialer & text entry:** As you type, each number or letter is read out loud.

Tip: Navigate through your menus to hear how voice readouts work on your phone.

CALLER ID

When you want to hear who's calling:

- **Read out loud:** Have your caller announced-touch **Menu**  > **Settings** > **Voice Playback** > **Speak Caller**.
- **Ringtones:** Assign a unique ringtone to a contact - press **Menu**  >  **Contacts**, highlight a contact, then touch **Menu**  > **Edit** > **[Ring Tone/Pict]** > **Ringer**, and select a ringtone. When finished, press **Save**.

VOLUME & VIBRATE


Choose volume and vibrate settings that work for you.


- **Volume:** Press the **Volume Key** up to raise the volume, or press the **Volume Key** down to lower it.
- **Vibrate:** Press the **Volume Key down** until the phone vibrates.

HEARING AIDS

To help get a clear sound when using a hearing aid or cochlear implant, your phone may have been rated for use with hearing aids. If your phone's package box has "Rated for Hearing Aids" printed on it, then please read the following guidance.

Note: Ratings are not a guarantee of compatibility, see "Hearing Aid Compatibility with Mobile Phones" in your legal and safety information. You may also want to consult your hearing health professional, who should be able to help you get the best results.

- **Settings:** Press **Menu**  > **Settings** > **Phone Calls** > **Hearing Aid**. Select **Microphone** to optimize your phone for microphone coupling, or select **Telecoil** to optimize your phone for telecoil coupling.
- **Call volume:** During a call, press the side volume keys to set a call volume that works for you.
- **Position:** During a call, hold the phone to your ear as normal, and then rotate/move it to get the best position for speaking and listening.



TTY

You can use your phone in TTY mode with standard teletype machines. Press **Menu**  **Settings** > **Phone Calls** > **TTY** > **On**, and select the mode you need:

- TTY: Type and read text on your TTY device.
- HCO: Hearing-Carry-Over type text on your TTY device and listen to voice replies on your phone's speaker.
- VCO: Voice-Carry-Over speak into your phone and read text replies on your TTY device.


Note: You'll need a cable/adaptor to connect your TTY device to the headset jack on your phone. Refer to your TTY device guide for mode and usage information.

SECURITY

PHONE LOCK

Find it: **Menu**  > **Settings** > **Security** > **Phone Lock** > **Lock Now** or **Auto Lock**

CHANGE UNLOCK CODE

When you receive your phone, your unlock code is **0000**. To change your unlock code, press **Menu**  > **Settings** >

Security > **Change Passwords** > **Unlock**

Code. Enter the current unlock code and enter the new four-digit unlock code. Re-enter the new four digits unlock code to confirm.

KEYPAD LOCK



Find it: **Menu**  > **Settings** > **Security** > **Keypad**

LOCK YOUR SIM

To lock your SIM, press **Menu**  >  **Settings** > **Security** > **SIM PIN** > **On**.

Caution: If you enter an incorrect PIN code three times, your phone locks your SIM card and asks for your PIN unlock code.

CHANGE SIM PIN

To change your SIM PIN, press **Menu**  >  **Setting** > **Security** > **Change Passwords** > **SIM PIN**.



PUK CODE

To unlock your SIM PIN, you need to enter your PIN unlock code (PUK code) when prompted.

Note: Your PUK code is provided by your service provider.

GPS PIN

When you receive your phone, your GPS PIN is **0000**.

To change your GPS PIN press **Menu**  >  **Settings** > **Security** > **Change Passwords** > **GPS PIN**. Enter the current GPS PIN and enter the new four-to-eight digit GPS PIN. Re-enter the new four- to eight-digit GPS PIN to confirm.

FORGOT YOUR PASSWORD?

If you forget your password, contact your service provide.

SAFETY, REGULATORY & LEGAL

Battery Use & Safety

The following battery use and safety information applies to all mobile devices. If your mobile device uses a non-removable main battery (as stated in your product information details related to handling and replacing your battery, the battery should only be replaced by an approved service facility. Any attempt to remove or replace your battery, unless performed by a service representative, may damage the product and void your warranty.

Important: handle and store batteries properly to avoid injury or damage. Most battery safety issues arise from improper handling of batteries, and particularly from the continual use of damaged batteries.

DON'Ts

- Don't disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.
- Don't use tools, sharp objects, or excessive force to insert or remove the battery as this can damage the battery.
- Don't let the mobile device or battery come in contact with liquids. Liquids can get into the mobile device's circuits, leading to corrosion.
- Don't allow the battery to touch metal objects. If metal objects, such as jewelry, stay in prolonged contact with the battery contact points, the battery could become very hot.

- Don't place your mobile device or battery near a heat source. High temperatures can cause the battery to swell leak, or malfunction.
- Don't dry a wet or damp battery with an appliance or heat source, such as a hair dryer or microwave oven.

DOs

- Do avoid leaving your mobile device in your car in high temperatures.
- Do avoid dropping the mobile device or battery. Dropping these items, especially on a hard surface, can potentially cause damage.
- Do contact your service provider if your mobile device or battery has been damaged in any of the ways listed here.

Note: Always make sure that any batter, connector and compartment covers are closed and secure to avoid direct exposure of the battery to any of these conditions, even if your product information states that your mobile device can resist damage from these conditions.

Important: The Manufacturer recommends you always use authorized-branded batteries and chargers for quality assurance and safeguards. The warranty does not cover damage to the mobile device caused by non-authorized batteries and/or chargers.

Disposal: Promptly dispose used batteries in accordance with local regulations. Contact your local recycling center or national recycling organizations for more information on the proper disposal of used batteries.

Warning: Never dispose used batteries in a fire because they may explode.

Battery Charging

Notes for charging your product's battery:

- During charging, keep your battery and charger near room temperature for efficient battery charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take time to charge.
- Hi-P batteries and charging systems have circuitry that protects the battery from damage caused by overcharging.

AC/DC Adapter

Mains Plug:

- Use 3-pin mains plug that is registered with the Singapore Safety Authority.
- Use 2-pin mains plug which is comply to EN50075.

Flexible Cord:

- Use a double insulated flexible cord that is certified* to the relevant IEC standards.

Appliance Connector

Use an appliance connector certified* to IEC 320.

Certified by member of IEC CB Scheme.

Third Party Accessories

Use of third party accessories, including but no limited to batteries, chargers, headsets, covers, cases, screen protectors and memory cards, may impact your mobile device's performance. In some circumstances, third party accessories can be dangerous and may void your mobile device's warranty.

Driving Precautions

Responsible and safe driving is your primary responsibility when behind the wheel of a vehicle. Using a mobile device or accessory for a call or other application while driving may cause distraction, and may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. **While driving, NEVER:**

- Type, read, enter or review texts, emails, or any other written data.
- Surf the web.
- Input navigation information.
- Perform any other functions that divert your attention from driving.

While driving, ALWAYS:

- Keep your eyes on the road.
- Use a hands free device if available or required by law in your area.
- Enter destination information into a navigation device before driving.
- Use voice activated features (such as voice dial) and speaking features (such as audible directions) if available.
- Obey all local laws and regulations for the use of mobile devices and accessories in the vehicle.
- End your call or other task if you cannot concentrate on driving.

Seizures, Blackouts & Eyestrain

To reduce eyestrain and avoid headaches, it is always a good idea to hold the screen a comfortable distance from your eyes, use in a well-lit area, and take frequent breaks.

Some people may be susceptible to seizures or blackouts (even if they have never had one before) when exposed to flashing lights or light patterns, such as when playing video games, or watching videos with flashing-light effects.

Discontinue use and consult a physician if any of the following symptoms occur: seizures, blackout convulsion, eye or muscle twitching, loss of awareness, or disorientation.

If you or someone in your family has experienced seizures or blackouts, please consult with your physician before using an application that produces flashinglight effects on your mobile device.

Caution about High Volume Usage

Warning: Exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the volume sound level the less time is required before your hearing could be affected. To protect your hearing:

- Limit the amount of time you use headsets or headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.



If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears, or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop using the product and consult a physician.

Children

Keep your mobile device and its accessories away from small children. These products are not toys and may be hazardous to small children. For example:

- A choking hazard may exist for small, detachable parts.
- Improper use could result in loud sounds, possibly causing hearing injury.
- Improperly handled batteries could overheat and cause a burn.

Supervise access for older children. Similar to a computer, if an older child does use your mobile device, you may want to monitor their access to help prevent

- Exposure to inappropriate apps or content.
- Improper use of apps or content.
- Loss of data.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Operational Warnings

Obey all posted signs when using mobile devices in public areas.










Potentially Explosive Areas

Potentially explosive areas are often, but not always, posted and can include blasting areas, fueling stations, fueling areas (such as below decks on boats), fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain dust, or metal powders.

When you are in such an area, turn off your mobile device, and do not remove, install, or charge batteries, unless it is a radio product type especially qualified for use in such areas and certified as "Intrinsically Safe" (for example, Factory Mutual, CSA, or UL approved). In such areas, sparks can occur and cause an explosion or fire.

Symbol Key

Your battery, charger, or mobile device may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
 	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not dispose of your battery or mobile device with your household waste. See "Recycling" for more information.
	Do not use tools.
	For indoor use only.
 	Listening at full volume to music or voice through a headset may damage your hearing.

Radio Frequency (RF) Energy

Exposure to RF Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your mobile device, the system handling your call controls the power level at which your mobile device transmits.

Your mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

RF Energy Operational Precautions

For optimal mobile device performance, and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions:

- When placing or receiving a phone call, hold your mobile device just like you would a landline phone.
- If you wear the mobile device on your body, ensure that the device is positioned at least 2.5cm (1 inch) away from the body, and if you use an accessory case or holder, ensure it is free of any metal.

Two-Way Radio Operation

Your radio product has been designed and tested to comply with national and international standards and guidelines regarding human exposure to RF electromagnetic energy, when operated in the two-way mode (at the face, or at the abdomen when using an audio accessory) at usage factors

of up to 50% talk/50% listen.

Transmit no more than the rated duty factor of 50% of the time. To transmit (talk), push the PTT button. To receive calls, release the PTT button. Transmitting 50% of the time or less, is important because this radio generates measurable RF energy only when transmitting (in terms of measuring for standards compliance).

When using your radio product as a traditional two-way radio, **hold the radio product in a vertical position with the microphone 2.5 to 5 cm (1 to 2 inches) away from the lips.**



RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances, your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn off your mobile device in any location where posted notices instruct you to do so, such as hospitals or health care facilities.

In an aircraft turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Medical Devices

If you have a medical device, including an implantable medical device such as a pacemaker or defibrillator, consult your healthcare provider and the device manufacturer's directions before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the mobile device is turned ON.
- DO NOT carry the mobile device in the breast pocket.
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Specific Absorption Rate (FCC & IC)

YOUR MOBILE DEVICE MEETS FCC AND IC LIMITS FOR EXPOSURE TO RADIO WAVES.

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) adopted by the Federal Communications Commission (FCC) and Industry Canada (IC). These limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 1.6 W/kg.

Tests for SAR are conducted using standard operating

positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the FCC and IC guidelines for your device model are listed below:

Head SAR	iDEN,Bluetooth	0.342 W/kg
Body-worn SAR	iDEN,Bluetooth	0.183 W/kg

During use, the actual SAR values for your device are usually well below the values stated. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value.

If you are interested in further reducing your RF exposure then you can easily do so by limiting your usage or simply using a hands-free kit to keep the device away from the head and body.

FCC Notice to Users

The following statement applies to all products that bear the FCC logo and/or FCC ID on the product label.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. See 47 CFR Sec. 15.105(b). These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

See 47 CFR Sec. 15.19(a)(3).

Hi-P has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

For products that support Wi-Fi 802.11a (as defined in product information): In the United States, do not use your device outdoors while connected to an 802.11a Wi-Fi network. The FCC prohibits such outdoor use since frequencies 5.15-5.25 GHz can cause interference with Mobile Satellite Services (MSS). Public Wi-Fi access points

in this range are optimized for indoor use.

Industry Canada Notice to Users

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device. See RSS-GEN 7.1.3. This Class B digital apparatus complies with Canadian ICES-003.

Software Notices

Warning against unlocking the bootloader or altering a product's operating system software: The Manufacturer strongly recommends against altering a product's operating system, which includes unlocking the bootloader, rooting a device or running any operating software other than the approved versions. Such alterations may permanently damage your product, cause your product to be unsafe and/or cause your product to malfunction. In such cases, neither the product nor any damage resulting there from will be covered by warranty.

Important FCC information: You must not make or enable any changes to the product that will impact its FCC grant of equipment authorization. The FCC grant is based on the product's emission, modulation, and transmission characteristics, including: power levels, operating frequencies and bandwidths, SAR levels, duty-cycle, transmission modes (e.g., CDMA, GSM), and intended method of using the product (e.g., how the product is held or used in proximity to the body). A change to any of these factors will invalidate the FCC grant. It is illegal to operate a

transmitting product without a valid grant.

Location Services

Location sources can include GPS, AGPS.

Your mobile device can use Global Positioning System (GPS) signals for location-based applications. GPS uses satellites controlled by the U.S. government that are subject to changes implemented in accordance with the Department of Defense policy and the Federal Radio Navigation Plan. These changes may affect the performance of location technology on your mobile device.

Your mobile device can also use Assisted Global Positioning System (AGPS), which obtains information from the cellular network to improve GPS performance. AGPS uses your wireless service provider's network and therefore airtime, data charges, and/or additional charges may apply in accordance with your service plan. Contact your wireless service provider for details.

Your Location

Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile devices which are connected to a wireless network transmit location-based information. Devices enabled with location technology also transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. This location-based information may be shared with third parties, including your wireless service provider, applications providers, and other third parties providing services.

Emergency Calls

When you make an emergency call, the cellular network may activate the AGPS technology in your mobile device to tell the emergency responders your approximate location.

AGPS has limitations and **might not work in your area**.

Therefore:

- Always tell the emergency responder your location to the best of your ability; and
- Remain on the phone for as long as the emergency responder instructs you.

Privacy & Data Security

Privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**-Keep your mobile device with you and do not leave it where others may have unmonitored access. Use your device's security and lock features, where available.
- **Keep software up to date**-If the Manufacturer or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible.
- **Secure Personal Information**-Your mobile device can store personal information in various locations including your SIM card, and phone memory. Be sure to remove or clear all personal information before you recycle, return, or give away your device. You can also backup your personal data to transfer to a new device.

- **Applications and updates**-Choose your apps and updates carefully, and install from trusted sources only. Some apps can impact your phone's performance and/or have access to private information including account details, call data, location details and network resources.
- **Location-based information**-Mobile devices enabled with location based technologies such as GPS, AGPS, can transmit location-based information.
See "Location Services" for more details.
- **Other information your device may transmit**-Your device may also transmit testing and other diagnostic (including location-based) information, and other non-personal information to third-party servers. This information is used to help improve products and services offered.

Use & Care

To care for your Hi-P mobile device, please observe the following:



Liquids

Don't expose your mobile device to water, rain, extreme humidity, sweat, or other liquids.



Drying

Don't try to dry your mobile device using a microwave oven, conventional oven, or dryer, as this may damage the mobile device.



Extreme heat or cold

Don't store or use your mobile device in temperatures below -10°C (14°F) or above 60°C (140°F). Don't recharge your mobile device in temperatures below 0°C (32°F) or above 45°C (113°F).



Dust and dirt

Don't expose your mobile device to dust, dirt, sand, food, or other inappropriate materials.



Cleaning

To clean your mobile device, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



Shock and vibration

Don't drop your mobile device.



Protection

To help protect your mobile device, always make sure that any battery, connector and compartment covers are closed and secure.

Recycling

Mobile Devices & Accessories

Please do not dispose of mobile devices or electrical accessories (such as Chargers, headsets, or batteries) with your household waste, or in a fire. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Hi-P Approved Service Center in your region.



Packaging & Product Guides

Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

California Perchlorate Label

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

Perchlorate Material- special handling may apply when the battery is recycled or disposed of. See www.dtsc.ca.gov/hazardouswaste/perchlorate (in English only).

There is no special handling required by consumers.

Hearing Aid Compatibility with Mobile Phones

Some phones are measured for compatibility with hearing aids. If the box for your particular model has "Rated for Hearing Aids" printed on it the following explanation applies. When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box. To maintain the published Hearing Aid Compatibility (HAC) rating for this mobile phone, use only the original equipment battery model.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Contact your service provider or Hi-P for information on hearing aid compatibility. If you have questions about return or exchange policies, contact your service provider or phone retailer.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Software Copyright

Products may include copyrighted Hi-P and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Hi-P and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in products may not be modified, reverse-engineered, distributed, or

reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the products shall not be deemed to grant either directly or by implication, estoppels or otherwise, any license under the copyrights, patents, or patent applications of Hi-P or any third-party software provider, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Content Copyright

The unauthorized copying of copyrighted materials is contrary to the provisions of the Copyright Laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright or materials which you are authorized or legally permitted to copy. If you are uncertain about your right to copy any material please contact your legal advisor.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

How to Obtain Service or Other Information

1. Please access and review the online Customer Support section of the service provider's consumer website prior to requesting warranty service.
2. If the Product is still not functioning properly after making use of this resource, please contact the Warrantor listed at the service provider's website or the contact information for the corresponding location.
3. To obtain warranty service, as permitted by applicable law, you are required to include: (a) a copy of your receipt bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) your address and telephone number. In the event the Product is not covered by the Limited Warranty, the Warrantor will inform the consumer of the availability, price and other conditions applicable to the repair of the Product.

Limited Global Warranty Mobile Phones

Statement of Limited Warranty

(The Seller) warrants that for a period of 1 year from the date of purchase that this product 1) is free from defects in materials and workmanship and 2) conform to its specifications. If this product does not function as warranted during the warranty period, (The Seller), at its option, will either replace this product with one that is functionally equivalent or will refund your purchase price. These are your exclusive remedies under this warranty. Please call 1-800 (The Seller's toll-free number) for warranty service.

This warranty will be voided by misuse, improper physical environment, accident, or improper maintenance by you. THIS WARRANTY REPLACES ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THESE WARRANTIES GIVE YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF EXPRESS OR IMPLIED WARRANTIES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. IN THAT EVENT, SUCH WARRANTIES ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD.

Circumstances may arise where, because of a default on (The Seller's) part or other liability, you are entitled to recover damages from (The Seller). In each such instance, regardless of the basis on which you are entitled to claim damages from (The Seller) (including fundamental breach, negligence, misrepresentation, or other contract or tort claim), (The Seller) is only liable for:

1. damages for bodily injury (including death) and damage to real property and tangible personal property; and
2. the amount of any other actual direct damages or loss, up to the greater of \$500 or the price paid for this product.

UNDER NO CIRCUMSTANCES IS (The Seller) LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR LOSSES OR DAMAGES (OTHER THAN THOSE UNDER THE FIRST ITEM LISTED ABOVE); (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATA: OR (3) SPECIAL, INCIDENTAL OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF (The Seller) IS INFORMED OF THEIR POSSIBILITY. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU.



AP1001049

